


# mulii

VERSION EN 24.1

## Instruction sheet Basket cover



## General information

Unfortunately, the cool water from above is unpredictable. That's why we have developed a lightweight basket cover that can be folded so small that it fits into a basket bag. Space-saving as it is, the basket cover can always be taken along to keep purchases and parcels dry during transportation. The basket can not only be covered completely, but also only partially if required. This not only protects further luggage, but also children's legs from the rain.

If you regularly travel with a laptop or rucksack in a closed basket or want to protect the folded basket from the rain in a tight parking space, you can also use the new basket cover. Two additional press studs in the lower area of the perforated plate allow the cover to be securely fastened even in the closed position.

In our download portal you will find these assembly instructions in German and other languages and always up to date: <https://muli-cycles.de/downloads>



## Text types / lists used



This manual uses the following text types and lists:

- 1 Instructions for action (in a fixed order)
- Instructions for action (in any order)


---

## Symbols / labels used


This manual uses the following symbols and markings:

-  The warning triangle in conjunction with the word “WARNING” indicates risks that can lead to serious personal injury or even death.
-  The warning triangle in conjunction with the word “CAUTION” indicates risks that can lead to minor personal injury and damage to property.


## Safety instructions

 **WARNING: Risk of falling and injury**  
The muli basket cover only serves to cover the top of the basket and is not designed for transporting loads or people on it. This would damage the basket cover and can result in serious falls and accidents.

- Use the muli basket cover exclusively as weather protection and do not transport any loads or people on it.

 **WARNING: Risk of falling and injury**  
The tensioning cover of the basket cover can cause the basket to fold in unintentionally while driving and thus cause the center of gravity to shift. This can result in serious falls and accidents.

- With open basket, always use at least one locking bar when using the basket cover.

 **WARNING: Risk of falling and injury**  
The cover can fall off due to incorrect or insufficient fastening when riding fast or in strong winds and impair the rider's field of vision.

- Always use the Loxx screws and press studs provided to attach the basket cover. And make sure it is securely fastened before every ride.

## Assembly Instructions




FIG. 1

### 1 BASKET COVER

- 2 x Loxx screw
- 2 x M5 self-locking nut
- 2 x Washer M5
- 4 x push button with screw
- 4 x M4 self-locking nut
- 4 x Washer M4

### TOOLS REQUIRED

- 2 1 x Allen key 3 / HEX 3
- 3 1 x open-end wrench 7 mm
- 4 1 x open-end wrench 8 mm
- 5 1 x open-end wrench 9 mm

## Fitting the basket cover

- 1 Insert the Loxx screw from the outside of the basket through the perforated plate in the position shown in Fig. 2. Place the washer M5 and the self-locking nut M5 on the thread of the Loxx screw from the inside and fasten the screw with the open-end wrenches 8 mm and 9 mm. Repeat the process for the other half of the basket.



FIG. 2

- 2 Fit the front press studs at the position shown in Fig. 3. Insert the screw through the push button and guide it through the hole indicated. Fasten the screw from the inside with the M4 washer and the M4 self-locking nut. Use a 3 mm Allen key and 7 mm open-end wrench.
- 3 Fasten the rear push button in the same way in the position shown in Fig. 4. Repeat the procedure on the other half of the basket.




FIG. 3




FIG. 4

## Covering the open basket

- 1 To attach the basket cover to the open basket, stretch the basket cover over the basket so that the Velcro fastener points backwards towards the steering tube. (Fig. 5)

Important! Always use at least one locking bar so that the basket does not fold up unintentionally during the ride due to the tension of the basket cover.

- 2 Tension the basket cover evenly over the basket and secure the basket cover to the basket on both sides using the upper LOXX screws. (Fig. 6)
- 3 Then place the Velcro fastener around the steering tube below the top tube and secure the basket cover. (Fig. 7)



FIG. 5




FIG. 6



FIG. 7

## Covering the closed basket

- 1 With the basket closed, secure the cover to the left and right of the basket wing using the four press studs at the bottom. The Loxx screws in the upper area remain unused. (Fig. 8)
- 2 Then place the Velcro fastener around the steering tube above the top tube and fix the basket cover. (Fig. 9)




FIG. 8



FIG. 9

# Imprint



BA-EX-14V24.1  
©muli cycles GmbH

Widdersdorfer Str. 190  
50825 Köln

**Text and graphics**  
muli cycles GmbH

**Photography**  
Tim Kaiser

**Illustration**  
Markus Färber

**Design**  
Friederike Wolf, Frieder Oelze



[www.muli-cycles.com](http://www.muli-cycles.com)